

PRODUCT MEASUREMENTS

	LT	XLT	2XLT	3XLT	4XLT
Chest	23 1/4	24 3/4	26 1/4	28 1/4	30 1/4
Length	33	34	35	35 1/2	36
Sleeve Length	37 1/2	38 1/4	39	39 3/4	40 1/2

CHEST

Measured across the chest one inch below armhole when laid flat.

LENGTH

Measured from center front neck to hem.

SLEEVE LENGTH

Start at center of neck and measure down shoulder, down sleeve to hem.